

Impact Test	UNI EN ISO 6272-2-2006. 1 kg doming punch was dropped from different heights and only at the height of 8 cm., it left a 5.5 mm. dent in the surface and a tiny crack appeared around its circumference.
Pencil Hardness	ASTM D3363- Pencil hardness 5H
Shore Hardness	Norm ASTM 2240 average
Adhesion	Norm UNI EN 13892-8 2004 average value = 2,0
Shelf life	36 months when stored according to the recommended guidelines
Storage	In original sealed packaging between 5° - 35°C in a dry, dark environment
Safety Norms	Irritating. / Risk of serious damage to eyes. / Irritating to the skin. / Keep out of children. / Avoid contact with eyes. / In case of contact with eyes, clean immediately with water without rubbing them, and consult a doctor. / Wear suitable gloves and eyes / face protection. / In case of ingestion of the products, consult immediately a doctor showing him the can or the label of the product. Danger labelling under directives 67/548/EEC and 1999/45/EC and following amendments and adjustments. The product must be transported, used and stored according to current standards of hygiene and safety.
Disposal	Product must be disposed of according to norms and regulations in force. Containers must be sent for recycling. Follow directions on the packaging
Application Instructions	<p>WARNINGS</p> <p>Water on the surface of the material in the bucket is normal and should be removed before use or addition of colourants. All lime-based products lose their viscosity when mixed and need a period of 6/12 hours after mixing to regain their density. This product is dense, and ready for use; thus it may be necessary to use an appropriate drill attachment to stir for a few minutes to reduce viscosity. Choose the colour and add the toner additive to the container and continue mixing until a homogeneous shade is obtained. Let the product rest for about 5 hours before you begin to use it.</p> <p>We recommend using materials from the same production batch for the same project. If you must use different batches, we suggest mixing their material together to avoid any slight variations in shading.</p> <p>To ensure proper usage, dilution, and application of the products mentioned in these pages, please consult the corresponding technical data sheets.</p> <p>When preparing the surface and applying the materials, we advise using appropriate tools and personal protective equipment (PPE).</p> <p>During application and for the following 72 hours, protect the surfaces from sudden temperature change, direct sun light and water. Don't apply in temperatures below 8°C or above 35°. During application make sure that the work area isn't too damp to avoid problems with application times.</p> <p>Remember to have a strong light parallel to the wall and situated on only one of the two sides of the wall you are working on (usually on the same side as other sources of light such as windows). In this way the shadow of the trowel allows you to see the actual state of the finish. Every so often, during the second and third coat, the light should be moved so that the wall doesn't dry out too much in one spot from the heat of the lamp.</p>

APPLICATION

Protection of the work area: Masking tape and protective material over the baseboards and around windows and doors.

DOLOMIA, can be applied on rough and smooth plasters, new and old. Existing paints need good brushing to remove surface dust and the inconsistent parts. Where necessary, apply a layer of QUARTZ PRIMER or UNIVERSAL PRIMER laid with a brush or roller, diluted with water according to the instructions.

The application must be carried out with a steel trowel in two coats. The application of the first coat is carried out with a metal trowel with a consumption of about 1800-1900 g/sqm. The next day, or at least when the first coat is completely dry, apply the second one with the same method and consumption. When the surface begins to dry, level it up with SPONGE FLOAT COARSE. Let it dry about a 30-40% and then press the surface with the blade of the metal trowel. If you do this smoothing too soon, you risk smoothing out all the surface, almost like a Marmorino. If you do it too late, you fail to create smooth areas that, in a properly applied finish, must alternate with the rough ones. This pressing can be continued until the smooth area becomes almost shiny. The blade has to be moved in different directions to avoid the creation of ridges ("chatters").

EXTERIORS

For exterior applications there are some rules to respect and some precautions to take. We remind you that carbonation, i.e. the process that takes place through the absorption of atmospheric CO₂, is completed in a few hours on the surface but takes several days to take place in depth. It is therefore important that the application takes place in the certainty of the absence of heavy rains in the three following days. It is also not recommended to apply it on walls that do not have at least a small roof overhang. Penetrating rain could ruin the finish even after weeks as deep carbonation is completed after more than a month. Avoid windy days, especially at high temperatures, as well as the risk of frost in the 48 hours following application. In external applications in hot climate conditions, it is also recommended to protect the wall from the sun with shade cloths applied to the scaffolding. Lime-based products must dry slowly to better fulfil their characteristics.

The application should be continuous and without linear brakes in the wall.

Finish Protection

Interiors: A protective treatment is optional in most circumstances. It is however necessary in bathroom, kitchen, and splashback walls.

Exteriors: This finish, as all lime-based plasters, absorbs water during rainy weather, which results in a temporary "wet effect" on the surface. However, this plaster releases the absorbed water within a few hours, allowing the surface to dry without any damage nor alteration to the finish. While a final treatment is therefore optional, it is highly recommended in areas with high pollution levels or if you wish to avoid the temporary wet effect that can occur after rainfall.

INTERIORS / EXTERIORS: after about 72 hours at least 20°C., proceed with the application of the colourless protective impregnation HYDROCALCE, especially



designed for the protection of external lime-based coatings. Its Installation is done by brush in two coats, with a consumption of about 100-130 g/sqm.

Maintenance

Little maintenance is needed, brush off dust occasionally.

Tools

SI TROWEL, SPONGE FLOAT COARSE, SCRAPERS
Clean with water immediately after use

We have drawn up the material presented above to the best of our technical and experiential knowledge. Nevertheless, our suggestions and recommendations are not guaranteed. All responsibility for the obtained results lies solely with the method and conditions adopted for the application of the product. Such indications constitute valid support for verifying the product's suitability for the specific case. We reserve the right to make modifications to the present information without previous warning.